

## USB to RS232 Adapter Win7 Setting

If you has been installed the USB device driver, you can see the Ports (under image)list the item”Prolific USB-to-Serial Comm Port(com?)”on the device Manager panel ◦

You must be to update the COM3(default) to COM1 , Pls. reference under steps to work ◦





