

TOPigeon Club Manager User Guide



TOPIGEON

Topigeon Electronics Timing System

Club Version

iPigeon

Enter

Avance Technology Co., Ltd.

TEL: +886-2-25163676

The advertisement features a dark blue background with a glowing globe graphic. Two black iPigeon timer devices are shown: one from the front and one from the back. The front view shows a screen and several buttons. The back view shows a lens and a small display. A blue button with a green arrow and the word 'Enter' is positioned to the right of the devices. The company name and phone number are at the bottom right.

The Next Generation Timer

June 2018



Support Information

To be informed of the latest updates and manuals please visit

www.TOPigeon.com


This Manual was updated
based on firmware version

V8.51

V 8.0 which was released in

May 2015

To check which versions of software you are using go to the setup Tab





Content

Content	3
Getting Started.....	5
Connection cables.....	6
VCP Cable	7
USB-COM cables	7
Install Club manager software	8
Software Protection	8
System region and time setting	8
Coordinate data entry.....	9
Data entry	9
TECS .ini file setting	10
Basic Operation	10
Home tab	12
Setup Tab.....	12
Adding new members.....	13
Editing members.....	15
Download loft information into member's clock.....	15
Adding Rings.....	18
Adding multiple rings.....	19
Add/Delete Birds color.....	20
Basic system operation.....	21
Clock Synchronization	21
Marked Data Upload	23
Race operation.....	25
Add new race	25
Multiple date racing.....	25
Add/Edit/Delete Liberation Point	26
Add/Delete Club Information	27
Loft Distance	28
Race Status	29
Race Result Upload.....	30
Advance Features	31
Manually input external clock	31



Import/Export member birds list.....	32
Export Race Result	33
Import Club Race Distance	33
Generate Winspeed File (US).....	34
Reports.....	36
iPigeon Clock Club Management.....	36
Authentication Key.....	37
Set Time	39
Summer Saving Time	39
Manual Adjust the Club antenna master time	40
Manual synchronize to iPigeon clock	40
Connect to PC.....	41
Ring Assignment	42
Print Assignment Ring List	42
Race Marking	43
Unmark Birds	46
Race Manager	47
Add Race	47
Close/Delete Race.....	48
Close Race (Race Finalization)	48
Arrival Mode (Race in Progress).....	50
Delete Race.....	51
System Test	51
Club Antenna Operation.....	53
Declaration of Conformity	57
iPigeon Timer	57
4 Channel Landing Board.....	58
1 Channel Landing Board.....	59
Club Antenna.....	60
iPigeon Technical Data.....	61



Getting Started

Welcome to TOPigeon V8.0 iPigeon Club manager software user guide and iPigeon clock club management user guide. The V8 iPigeon can operate without any computer, if your club does not have any computer you can go directly to the Club management chapter in part 2. You will find this is a very useful tool to help you manage the club system, as well as the member's timer. You will also find the most advance feature that the system can provides accurate racing result.

You might already review the iPigeon timer user manual and knowing that iPigeon timer can work independently without connecting computer. **Please note that the information you create the birds or races manually in iPigeon will not be synchronized to this club manager software.** If you are in the larger pigeon race club organization, the iPigeon club manager will provides you a better way to manage your members, timers, birds and races. These key features are,

1. To keep club members, timers, birds, and flight data secure and integrity.
2. To initialize iPigeon clock to the manufacture default setting.
3. To initialize vital the communication settings, such as host name and SMS center number, which allow you to use the TOPigeon online cloud database and view your result online.
4. To allow you create new member and loft information easily.
5. To create race activities swiftly.
6. Batch mode import and export to provide easy way to add new member information.
7. Easily print out and sorting for all information in the club system.
8. Automatic system backup to secure all information in the system.
9. Manually enter the other clock information for racing result
10. Export the result to Excel spreadsheet for the club further result process.
11. By using iPigeon coordinate information will automatic calculate distance in racing result!

Before you begin please note that the TOPigeon timer is a sophisticated electronic device and it needs some specific setting in your personal computer. Please read this manual and follow the instructions.

Connection cables

Before you use the club antenna firstly check your cable connections with your laptop or personal computer.

1. Virtual COM Port cable
2. RS-232 cable. (Optional)
3. USB to RS-232 cable (Optional)



VCP cable



RS-232 and USB cables

The RS-232 - USB cables and VCP cable, either way can connect club antenna to your personal computer.



VCP Cable

Virtual COM port (VCP) cable is for the USB device to appear as an additional COM port available to the PC. Application software can access the USB device in the same way as it would access a standard COM port. The VCP cable is also the standard cable come with TOPigeon club system package.

The VCP capability is using the chip of FTDI FT-D232 in the club antenna. By using the VCP cable, PC can automatic find the driver in the Window 8.1 or above with plug and play (PNP). The specific drivers for different Microsoft Window operation systems, such as x86-32/64 bit can be found in following web site:

<http://www.ftdichip.com/Drivers/VCP.htm>

This website provides the automatic installation program and after you install the driver the plug and play (PNP) will help to finish the installation. If you are using VCP cable please make sure the club antenna power is on. You can double check the readiness of COM port by going to your Device Manager in the Control Panel. Go to the Ports (COM&LPT) and you should see the USB Serial Port.

USB-COM cables

The USB and RS-232- COM cables have to connect together between club antenna and PC. The USB to RS-232 cable has a chip inside to convert the protocol. This cable needs driver to activate in your PC. If you have the driver installed properly you will find the COM Port in your Device manager in control panel and does not need the club manager power on.


The iPigeon Club antenna IO port as below,



Install Club manager software



There might be a software protection on your Microsoft Windows system, especially the Windows 10.




You can just ignore the warning and click the **Run anyway** to proceed your installation.

System region and time setting

Since iPigeon timer is using ISO date/timing internally and this format needs to follow for the result calculation. The standard long date/time format is YYYY-MM-DD and HH/MM (24 hours system). This format is the iPigeon internal format. You need to customize your personal computer accordingly in order for the club manager to calculate the result. Please go



to the region setting on your personal computer's control panel and change the format accordingly.



Coordinate data entry

The coordinate data entry is important in the system if you want to use this tool to help you generate the race result. Please make the best use of the GPS module come with the TOPigeon package. All member and race information, the coordination is mandatory and cannot leave empty. If you do not have coordination information please enters the dummy data and does not use the race result feature. Please note that coordinate format in the tool cannot be space. For example: N 24°22'3 and the entry should be N024°22:03.


Data entry

There are some small TIPS for you to enter the data easier, such as well use of your key board "Tab" Key and "Arrow keys". For example, there are many fields to fill in. If you finished one field and press Tab key, the cursor will move to the next field. If you enter multiple column data such as coordinate, date, and time. You can move the column by press -> to move to next column.



TECS .ini file setting

There are some vital parameters inside this initiate file before you run the club manager system. You can find the TECS.ini file in your Program files (X86)/advancetech/ClubSys_V8



```
TECS.ini - Notepad
File Edit Format View Help
[Parameter]
CountryRingCode='GB,SU,IHU,WHU,NEHU,NWHU,NL,BELG,DV,FR,SA,PL'
APN='emome'
HostSms='886911511568'
```

You can edit this file by Notepad.

CountryRing Code: The list inside is following the Europe Union/Association standard and this will be your prefix of association number. You can edit it according to your Unions and Associations.

APN: Access Point Name which is basic setting for the iPigeon timer 3G data. This will be the default setting when you initiate a new iPigeon timer. In the iPigeon timer itself, the fancier can also change the setting if they change a SIM card.

HostSMS: This is the SMS center phone numbers setting which fanciers are not allow to change. The SMS center system can receive and send SMS of club race information to fanciers mobile. This function can provide by either GSM module or HTC Mobile APP. Please contact TOPigeon for more information.

Basic Operation

This software designed in the way for the people not familiar with computer and soon feels comfortable with it. You just follow the top tab buttons to go through all club operations. For all data lists, if you click on the top row, the list will be sorted according to the row you click. If you right click on your mouse over a data record, a popup window appears for your further operation options, like **delete**, **add**, and **edit**.

When you double click the iPigeon club manager icon on your computer desktop, the applications will check the COM port connection firstly. If no COM port connection, the



system will prompt you an error message. This is to make sure that your COM port has dedicated to this program. Please note that the club manager will detect the COM port automatically.




The password for the club manager will be given by AdvanceTech or your local agent. This password also data encryption key of club manager system and it will be different between clubs.






Home tab



The Home Tab will show the system logs that this club manager has down load data or synchronized with your club members. This provides a basic tracking record of the club operations.

Setup Tab

Note: If you are first time using this club manager software; the club system will direct go to this Tab first and ask you to fill in the information.



In this Setup Tab is all about the Club information and system setting and they are all basic information but vital to the club operations. Some key fields explain as below




Club Abbreviation: If your club is not in the club abbreviation list please select “custom”. Please note the Club Abbreviation will be the **CLUB ID** when you initiate the new timer for your member. The **CLUB ID** is a very important identifier when your member wants to check the online result. The maximum of **Club abbreviation** field is 8 characters.

Association: The Association code will be the default of the member loft ID. This is also an identifier which will insert into all data transmission to cloud database. The fancier can view their online result by using the Association code.

Please note: The Club Name and abbreviation are following by UK region. If you are in different region, please edit yourself in the TEC_ClubMap table.


There are **meters/minutes** (m/min) and **yards/minutes**(y/min) option for the different velocity unit. Please setup the metrics system according to your club rule.

The club manager database **automatic backup** period and backup time can also be configured in here as well.




Adding new members

3 Select the Members Tab at the top of the screen



Select the “AddNew” button to add new members.



Enter your member’s details and loft information. Click Save when you have entered all the information. Some important fields are,

Telephone Number: If you are using TOPigeon SMS Center system, the system will collect this information as the member mobile number. The club can broadcast race information or send the race result to the individual mobile phone via SMS.


Loft number: The first field will come with the **Setup, Association**. You can also edit this field if this code is not correct. Please note this code will be update to the fancier timer accordingly. The second field is the real Loft number, or called Loft ID which will update to the fancier’s timer as well. This loft number will be the identifier for the loft in the backend system.



Loft Coordinate: This Loft coordinate information is a fix value update to the Fancier information in the timer which is different from the **GPS coordinate** from the Summary Information in the timer. If you are using TOPigeon loft monitor system, the monitor system will be alarm if these two coordinate are drifted over, say 300 meters (configurable), in order to detect the fraud like changing loft location.

Editing members

Select the Members tab a list of all your members will be displayed. Hold mouse over member you wish to edit, and then press the **RIGHT MOUSE BUTTON** for further options




Edit Member” to change members addresses or details. **Delete Member**” to delete the member from Club Manager

Members Ring List” to view their ring list, which will be the same as you double click on the member’s row. The function will be introduce later.

Members Clocks” to view member Clocks information, clock serial number and time last synchronized.

Download loft information into member’s clock

Before you operate this process make sure the member’s clock and PC already connected and member’s clock is in **Connect to PC**” Status.




There are three situations that you need to use this features,

1. Fancier purchase new iPigeon timer.
2. Fancier's iPigeon timer transfer to another fancier.
3. Fanciers change their member information, such as phone number, address or new loft location.


The situation one and two need to initialize iPigeon timer and situation three do not need to initialize the timer. A simple thumb of rules, only the timer change the **loft number** or new assign the **loft number** need to initialize the timer.


Right click over the member's row and select the "**Loft Data Download**"




A confirmation window will pop up **“Do you want to initialize this timer?”** The difference of this confirmation window will be,

1. **“YES”**: This will initialize the member’s clock by clean up all loft data, including the pigeon information, and load the new loft data to the clock as for situation one and two.
2. **“NO”**: This will keep all existing data and update the new loft information to the timer. This feature is for the situation three.





When download new loft data completed a message of “**Loft data Download success!**” will pop up in the club manager. The iPigeon will also display Data Download success! Message as below,



Adding Rings

From the Members screen, if you double click the member line or right click on mouse and Select “Members ring list” to Add member ring’s window as below, Use the “AddNew” button to add birds.

[H Home](#) | [C Clock Operation](#) | [M Member](#) | [R Races](#) | [S Setup](#)

Melchor de Asis's Ring List

Number of rings : 003

Life Ring Number	Color	Sex of bird	Ring Assignment	Create Date	Assign Date
MMFC 15 - 23235	Blue Chequer	Cock		2015/5/12	
MMFC 15 - 23236	Blue Chequer	Cock		2015/5/12	
MMFC 15 - 23237	Blue Chequer	Cock		2015/5/12	

Association :

Birth Year:

Registration Letter :

Registration Number :

Sex of the bird :

Bird color :

Upper registration number :

Comment :

In the bottom part of the screen select the Association by either using the drop down list or pressing the first letter “G” for example will bring up “GB”

By using the “TAB” key you can switch between the fields: **Birth year**, **Registration Number** and etc. Enter the **Bird color** and **Sex of bird** if known. You can edit this information later.

When you have entered the entire pigeon information click “**Save**”

For adding each ring Click the “**AddNew**” button to add more rings.

Adding multiple rings

One of the nice features of Club Manager is that you can add a certain range of the rings for the member new birds batch process. By select the “**Add a Range**” button. Then the “Upper registration number” field will show. By fill in the range of registration number from starting and ending (Upper registration number), the whole range of the rings will



populate in the upper window.

Melchor de Asis's Ring List

Print Number of rings : 003

Life Ring Number	Color	Sex of bird	E_Ring Assignment	Create Date	Assign Date
MMFC 15 - 23235	Blue Chequer	Cock		2015/5/12	
MMFC 15 - 23236	Blue Chequer	Cock		2015/5/12	
MMFC 15 - 23237	Blue Chequer	Cock		2015/5/12	

Association : MMFC
Birth Year : 15
Registration Letter : -
Registration Number : 23235
Sex of the bird : Cock

Bird color : Blue Chequer

Comment :

AddNew Add a Range
Spreadsheet Import
Spreadsheet Export
Save Cancel

The detail of the individual pigeon information can be edit later.

Add/Delete Birds color

Select one bird color and the Bird color dropdown box and right click on the mouse.

Add/Delete manual will show.

Tunduc Marius's Ring List

Print Number of rings : 002

Life Ring Number	Color	Sex of bird	E_Ring Assign	Create Date	Assign Date	st Upd
16_234564	Other	Cock		2016-03-25		
16_234565	Other	Cock		2016-03-25		

In Bird color field select one color and right click on the mouse

Bird color : Yellow

Association :
Birth Year : 2016
Registration Letter :
Registration Number : 234565
Sex of the bird : Cock

A Add
D Delete
E Exit

AddNew Add a Range
Spreadsheet Import
Spreadsheet Export
Save Cancel

To delete the clock just check "delete". To add color an adding window will show to enter the color code and color name.

[H Home](#) | [C Clock Operation](#) | [M Member](#) | [R Races](#) | [S Setup](#)

Tunduc Marius's Ring List



Topigeon Electronics
Timing System
iPigeon
Avance Technology Co., Ltd.
TEL: +886-2-25163676

Number of rings : 002

Life Ring Number	Color	Sex of bird	E_Ring Assign	Create Date	Assign Date	st Upd ^
16_234564	Other	Cock		2016-03-25		
▶ 16_234565	Other	Cock		2016-03-25		

Association : Bird color : Comment :

Birth Year :

Registration Letter : Bird Color Maintain

Registration Number :

Sex of the bird :

Color Code :

Color Name :

Basic system operation

The basic club operation, including clock synchronization, Marking upload and Race Result upload will be introduced in the follow sections,

Clock Synchronization

There are 3 major club operation needs to do this **Clock Synchronize**,

1. **New Rings data upload and download**
2. **Assignment data upload.**
3. **Race data Download (No upload).**
4. **Delete old race data (5 days earlier).**

All of above operation needs to synchronize the data to keep data integrity. If you **skip synchronize** procedure the system will prompt you an error message.

Again before you synchronize your timer this need to be **“connect to PC”**. Click the **Club management** in the iPigeon main menu. Then click **“connect to PC”** button, then you will get **“Connecting.....”** screen.

As you can see that Ring Marking (Basketing) and Ring Assignment all in this menu, but you do not need to connect to PC for these operations.




You will find there are two button in the Synchronize clock page” – **Sync Now** and **Sync Auto**.


Sync Now: One time synchronization when you press the button.

Sync Auto: The synchronization action will start every 5 seconds. This is for the club batch operation, such as during basketing/ marking process all member timers have gather together.

Sync All: If you have any trouble on synchronization both on the clock or club manager, this button can help you to synchronize all data from the clock to the club manager at once. Please note it will take some time if you have more data on the clock.



After synchronize complete, system will prompt the status, such as “In synchronize” and “successful”. The iPigeon clock will also prompt the message “Synchronize Success!”




Marked Data Upload

Most of other brand products do not have this feature because they are not providing the result calculation. If you do not want the club manager to calculate the result for you and you do not need to do this operation.


Please note:

1. Before you move to this function make sure you have synchronized the assignment data to this system.
2. You cannot upload the manual created race marked data.

After marking you can upload the marked data to the club management system. You have to do this process before member's bird arrival. The process is very simple by going to the **Mark Upload** page in the **Club Operation** tab. Select the **Race Code** that you marked and wait for the system upload automatically. System will also prompt you the status as below,




The Clock will also prompt “Marked data upload success!” message.



Race operation

Add new race



In the Race TAB, it shows all race point created. To create new race, you click on “Add New”, then you enter race information in the **Liberation Point Detail**. You can also reuse the existing liberation site by selecting the scroll bar of **Liberation Site**. If it is new liberation site, you need to check on “**Customized LibPoint**”, to enter new liberation point. After you enter all race information, click the “Save” button to save all racing information.

Note:

1. The Liberation code must not over 4 characters. The race code will generate automatically in the system by combine the Lib code and Lib date, such as race code 1122 and Lib date is 0526, the race code will be 1122/0526.
2. The Coordination may leave empty. If you do want the club manager to calculate the result of speed you **MUST** enter the coordinate.

Multiple date racing

If your pigeon racing will across one day, you **MUST** to set the **Sun Rise Time** and **Sun Set Time** in the **SunDataSeting** in order to get **Hour of Darkness (HOD)**.

The screenshot shows the 'Race Points' window in the TOPIGEON Club Management V8 software. The window has a menu bar with 'H Home', 'C Clock Operation', 'M Member', 'R Races', and 'S Setup'. The main area displays a table of race points. A red circle highlights the 'Race Date', 'Location', 'Sunset', and 'Sunrise' columns. Below the table is a 'Liberation Points Detail' form with fields for Club, Liberate Site, Liberation Site, Longitude, and Latitude. The 'Customized LibPoint' button is visible.

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
AVANCE	9999	TAINAN	Taiwan Tainan	2015-10-01	16:35:00
MAIT	7777	SYD			
▶ IPIGION	3344	MAIT			

Race Date	Location	Sunset	Sunrise
yyyy-mm-dd		hh:nn:ss	hh:nn:ss
2015-10-23	Sydney	18:00:20	06:02:30
2015-10-24	Mailand	18:01:20	06:05:20

Enter the data by following the date and time format on top of the row. The system then will automatically calculate the flying time by deducting the HOD.

For example a cross one day race, liberate on 23rd of Oct. 15 and birds return on 24th of Oct, you must set **Sunset and Sunrise in two rows in 24 hours format**. As such, 3 days there should be 3 lines and the rest can be done in same manner.

Please Note: For multiple date race you **MUST** set the **Sundataseting** or the result will not be calculated.

Add/Edit/Delete Liberation Point

You can always Add/Edit the Liberation point by clicking on the **Customized LibPoint** button. You can also delete the liberation point as follows procedure.

H Home | C Clock Operation | M Member | R Races | S Setup

Race Point



Topigeon Electronics Timing System
iPigeon
Avance Technology Co., Ltd.
TEL: +886-2-25163676

Print

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
▶ 168	2346	TAK	Taipei Station	2016-03-29	14:16:20
CORP	5566	OTINA	Otina	2016-03-29	14:16:20

Liberation Points Detail

Club : Liberation Date : 2016-03-31 Liberation Time : 14:16:20

Lib Site Site Abbreviatio : Liberation Code : 9999

Liberation Site : Customized Lib. Point : Customized LibPoint

Longitude : Latitude :

Set SunSet/Sunrise :

1. Go to the Liberation Site Abbreviation dropdown box and select the Liberation point you want to delete.
2. Right click on the mouse and check the delete button.

Add/Delete Club Information

The Club Manager is not only serving for single Club operation, but also serving Pigeon racing Federation or Association. When the Club manager dealing with many club and you will need the capability of adding and delete the Club information, such as Club name and Club abbreviations (Club Code). This feature is inside the RACE Tab,

H Home | C Clock Operation | M Member | R Races | S Setup

Race Point



Topigeon Electronics Timing System
iPigeon
Avance Technology Co., Ltd.
TEL: +886-2-25163676

Print

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
▶ 168	2346	TAK	Taipei Station	2016-03-29	14:16:20
CORP	5566	OTINA	Otina	2016-03-29	14:16:20

Right click on the Mouse

Liberation Points Detail

Club : Liberation Date : 2016-04-06 Liberation Time : 14:16:20

Liberate Site : Liberation Code :

Liberation Site :

Longitude : Latitude :

Set SunSet/Sunrise :

In the Club dropdown box, you can simply add or delete the Club information. After you click on **Add** you can enter the Club Name and Club Code accordingly.

TOPIGEON Club Management V8

H Home C Clock Operation M Member R Races S Setup

Race Point

Print

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
168	2346	TAK	Taipei Station	2016-03-29	14:16:20
CORP	5566	OTINA	Otina	2016-03-29	14:16:20

Liberation Points Detail

Club : grpClubMap

Liberate Site Abbr. ClubCode : []

Liberation Site : ClubName : []

Longitude : []

Latitude : []

Liberation Time : 14:16:20

Customized Lib. Point : Customized LibPoint

Set SunSet/Sunrise : SunData Setting

Save Cancel AddNew

Note: If you are using online transfer of the Race result the **Club Code** of the race will be transferred in the result. Not your own clock Club code.

Loft Distance

Please note you must update the loft distance to getting the speed in a race.

If you want this club manager to calculate the result automatically you have to operate this function before member's **Result Upload**.

TOPIGEON Club Management V8

H Home C Clock Operation M Member R Races S Setup

Race Points

Print

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
NTWC	AA11	SOUTH TAIW	South Taiwan	2015/05/21	16:20:00
NTWC	0000	TAIWAN	Taiwan Tainan	2015/05/22	10:00:00
NTWC	0000	NAGA	NAGA City	2015/05/26	10:16:20

- Edit Point
- Delete Point
- Distance
- Status
- Result
- Add/Edit other Clock

Liberation Date : 2015/05/26

Liberation Time : 14:16:20

Liberate Site Abbreviation : []

Liberation Code : []

Customized Lib. Point : Customized LibPoint


Set SunSet/Sunrise : SunData Setting

Save Cancel AddNew

Select the active race and left click on your mouse. You will see options that you can work on. Click on the **"Distance"**, you will see all your member loft distances to the liberation



point. Of course, the distance is based on the loft and liberation point coordination. You need to make sure that all these information has fill in correctly in order to calculate the right distance.




For new liberation point, click “**LoftDistUpdate**” to calculate the distance between liberation point to your member’s loft in kilometers and meters.

You can also overwrite the distance manually, by moving your cursor to the field and type in new distance. Press OK and leave this page the new distance will be saved.

Race Status


You can also check the race status by select the status button. The race status will show all you member’s marked and arrived of bird total number for this race and print out the overall report.



Race Result Upload

Note:

1. You have to print from the timer of **Race Finalization List** at least once before you can operate this function. Otherwise, you will get error message of print out first.
2. You have to do **Marked Upload** prior to **Result Upload**.



Again, the iPigeon timer needs to be “Connect to PC” status and go to **Clock Operation - Result Upload** tab. Select the proper race code from the **Race Code** scroll bar and click on




the proper race. As you can see the picture above the Fly speed and Flying time all been given after upload.

Advance Features

Manually input external clock

If your club has external clock which cannot upload to the club manager and you want to use the race result tool to generate report you can manually input the data. Firstly, you need to create the member and rings information in the system. In the Race TAB, left click on the race entry and select the “**Add/Edit other clock**”.



Make sure you have created member and member ring list. You can enter the clock setting data. When you select the ring number, you can either use select drop down box to select, or you can use the search field, by key in the last few digit of ring number, and in the select drop down box will show the select condition ring number. Next enter the date and time. You can simply enter the time by using arrow key. After complete the bird data entry, click on **Save** button to save.

Import/Export member birds list

When other club member wants to join to your club you can use import/ export features in the Member's ring list window. Firstly, you have to create new import member information. The member shown in the member list double click on the member will bring you to the member's ring list window. Edit the member's birds list from Microsoft Excel. Then click on the "import spreadsheet" select to the right file in the file manager. The birds ring list will be direct import to this member. You can also export to Excel spreadsheet if the member birds ring list like to migrate to other Club.

The screenshot shows the 'Melchor de Asis's Ring List' window in the TOPIGEON Club Management V8 software. The window has a menu bar with 'H Home', 'C Clock Operation', 'M Member', 'R Races', and 'S Setup'. Below the menu bar, there is a 'Print' button and 'Number of rings : 003'. A table displays the following data:

Life Ring Number	Color	Sex of bird	Ring Assignment	Create Date	Assign Date
MMFC 15 - 2213445	Yellow	Cock	007A.0002	2015/05/26	15/05/26 09:49:
MMFC 15 - 2213446	Silver	Cock	14123456	2015/05/26	15/05/26 09:49:
MMFC 15 - 2213447	White	Cock	131F0014	2015/05/26	15/05/26 09:49:

Below the table, there is a form for adding new birds with the following fields:

- Association : [dropdown]
- Birth Year: [dropdown]
- Registration Letter : [text input]
- Registration Number : [text input]
- Sex of the bird : [dropdown, set to 'Cock']
- Bird color : [dropdown]
- Comment : [text area]

Buttons include 'AddNew', 'Add a Range', 'Spreadsheet Import', 'Save', 'Cancel', and 'Spreadsheet Export'. A red arrow points to the 'Cancel' button.

Export Race Result

Pos.	Member	Pigeon	Clock	Flying Time	MPM	Dist.
1	YiHong	WHU 15 - 55002	09:40:11	0:0:9	1,374,726.625	209
2	YiHong	WHU 15 - 55003	09:41:59	0:1:57	105,748.203	209
3	YiHong	WHU 15 - 55001	09:40:19	1:13:14	2,815.781	209

The club manager can export the race result to Excel spreadsheet file for club. The club can use this export file to format their own result report or import to their existing system. The export button is located in the RACE tab. Result option, “result export”.

Import Club Race Distance

In many Associations and Clubs racing would provide their own distance to the loft/member for their own distance calculation and to keep authorities. The Club Manager provides the tool to import Club distance file for result calculation.

In the specific race information, right click on the mouse, then you will see distance download selection button in below,

H Home | C Clock Operation | M Member | R Races | S Setup

Race Point



Print

Club	Code	LibSite Abbre.	Liberation Site	Lib. Date	Lib. Time
168	7788	EROILOR	Eroilor	2016-03-15	14:00:07
168	5566	OTINA	Otina	2016-03-16	11:55:20
168	1111	OTINA	Otina	2016-03-16	14:33:20
		BUCURESTI	Bucharest suburben	2016-03-16	16:40:20
		BUCURESTI	Bucharest suburben	2016-03-17	12:30:20
		BUCURESTI	Bucharest suburben	2016-03-19	12:30:20

Edit Point
 Delete Point

 Distance
 Status
 Result
 Add/Edit other Clock
 Distance download

Liberate Site Abbrivatio :

Liberation Site :

Longitude : Latitude :

Liberation Date : Liberation Time :

Liberation Code :

Customized Lib. Point : Customized LibPoint

Set SunSet/Sunrise :

Check the box, then you will go to file selection windows as below,

H Home | C Clock Operation | M Member | R Races | S Setup

Race Point



Print

Race distance download				
Member	LoftNo	KM	M	
Tunduc Marius	130866	119	164	


File Selected :

After you click on the **File Selected** button, then you can select your distance file provided by your authorities. The current file format is following the RPRRA association in UK which is: Race point code, Fancier number, Miles.yards or KM.meters. After selection the distance will be load to the club manager for result calculation.


Generate Winspeed File (US)

Winspeed is the primary race calculation program used in the US, one of its attractions is the national database, a rating system that compares results of flyers and their birds a cross the US. Winspeed is a race calculation program developed by the AU (American Pigeon Racing Union) for clubs to use to calculate race results. The .doo file is created at strike off from the iPigeon. It is merged into Winspeed to create official results.

To generate the doo file is very easy in the club manager. You select the race you want to generate the doo file in the **Race Tab** and right click on the mouse and select “**Generate Winspeed File**”



Please not the race you select must strike off and **upload the result to the Club Manager.**



The Club Manager, then prompt the **Save As** window where you can select the directory you want to save to. The club manager will generate the .doo file for all races in the race week and named by the week according to the Winspeed regulation.

When generating doo file, there are 2 files of **liberation code** and **loft list** also generated for club personal or Winspeed entry references.



Reports

There are totally 9 reports in this club management software. They are,

1. Race marking report: When you finished all your birds marking for a specific race and you can print out marking report.
2. Loft to Liberate Site Distance List: The list of the distance from all your member loft distance in the club to a specific liberation site
3. All Member List Report: List of all the member with loft number in the club
4. Member Ring List Report: The member all birds ring number and matching e-ring number and marking information.
5. Race List Race: All active races in your club. If you have not deleted the race will be regarding as active.
6. Race Result Report: A specific race of all member result. Please note that if no distance and there won't be ranked.
7. Race Status Report: A specific race of all member race status, including birds marked, birds arrived.
8. Race upload report: This is the list of all member upload their race result which is different from the race result report.
9. Timer up load Record Report: When fancier upload to the club system can print out all up load data on site.

The 9 reports printout buttons are all in related function program. You can check whilst you operated in the specific function.

iPigeon Clock Club Management

All club operations requirements are in this function. Before you tap this icon, first please make sure that you have connected iPigeon clock to the club antenna by the **Mini DIN** cable. Secondly, you need the Authentication key.



There are 6 major functions when you connect to club antenna and use the authentication key correctly: **Set Time; Connect to PC; Ring Assignment; Race Marking; Pigeon Manager; Race Manager.**



iPigeon connecting to the club antenna



The Club Antenna operation will be introduced in the next session.

Authentication Key

The authentication key represents the club operation authority. Please keep the authentication key safely at all time. The club manager will be activated when you present the authentication key on the club antenna. Please also note that, once you leave the club



manager or completed an club operation you will need the authentication key again for follow up actions.





Set Time

Normally you should not use this features in all time, unless your club manager cannot grasp such as GPS time.


Note: If you are using a new clock, please go the **System Info** and double check if the time zone setting is correct:



Summer Saving Time

You do not need special setting for the summer saving time. Both Club antenna master time (including GPS) and iPigeon internal clock are using UTC time. You only need to change your clock **System Info – Time Zone** UTC to the new summer saving time zone. For example, you are in UTC +2 time zone and summer saving time change to UTC +3.

Note: You also need to change your club manager computer time to the new summer saving time.



Manual Adjust the Club antenna master time.



The upper site box indicates the current club antenna master time. The club master time can be adjusted by the club authority. If the club antenna indication LED blue light is flickering, then after manual time adjustment the LED blue light will stop flicking and turn on the blue light.


Manual synchronize to iPigeon clock.

Once press the RED button below the box, the iPigeon internal RTC will be synchronized by the club master time.

For the Set Time synchronization please note that,


1. During race basketing (Marking) process, the club antenna master time will automatic synchronize to iPigeon clock.
2. Manual time synchronization will be disabled if the iPigeon timer has any active race.

Connect to PC



This action is to set the iPigeon to designate the communication port to the club computer instead of club antenna. The club computer should have TOPigeon V8 club management software installed. The club manager software is for large pigeon club organizations to manage their members pigeon race activates. The operation of club manager software is not contained in this manual. Please refer to the **iPigeon V8 Club Manager User Guide** for detailed information.

Ring Assignment



The Ring Assignment screen is similar to the Pigeon Manager where you can **Add** and **Search** the specific bird that you want assigned. By selecting on the specific pigeon that you want to assign the chip ring and the **Assignment** button will be activated. Press the assignment button, a window will bring up “**Scanning...**” message. You can then swipe the chip ring on the club antenna to assign the bird. If you assign to the wrong chip ring it can **Restart**. Press **OK** to complete this ring assignment. You can also press **Cancel** to cancel this assignment.

You can also **Unassigned** by pressing the “Unassign” button. After you Unassigned, you can delete the unassigned bird.

Print Assignment Ring List

You can also print this assignment list for this operation for fancier or club to keep the record. The assignment ring list will printed be in two rows. The color of the bird will be also printed in the list for confirmation.

TOPIGEON - Assignment Ring List

CLUB: _____ CLOCK No: PRINTED: 21/01/2016 15:45:00
 MEMBER: _____ LOFT NUMBER: 12345678 TELEPHONE: _____
 ADDRESS: - -

No	Ring	IC	E-ring	No	Ring	IC	E-ring
1	BP-214-DNA-10001	Red	00000001	2	BP-214-DNA-10002	Red	00000002
3	BP-214-DNA-10003	Red	00000003	4	BP-214-DNA-10004	Green	00000004
5	BP-214-DNA-10005	Green	00000005	6	BP-214-DNA-10006	Green	00000006
7	BP-214-DNA-10007	Green	00000007	8	BP-214-DNA-10008	Green	00000008
9	BP-214-DNA-10009	Green	00000009	10	BP-214-DNA-10010	Green	00000010
11	BP-214-DNA-10011	Green	00000011	12	BP-214-DNA-10012	Green	00000012
13	BP-214-DNA-10013	Green	00000013	14	BP-214-DNA-10014	Green	00000014
15	BP-214-DNA-10015	Green	00000015	16	BP-214-DNA-10016	Green	00000016
17	BP-214-DNA-10017	Green	00000017				


Signed Member: _____ Club: _____ Clock Checked: _____

Sample of assignment ring list

Race Marking

Before you operate this process, please make sure that you have created a specific **RACE**. For race creation, please go to the “Race Manager” function, or you can create in the club management software and synchronize to the clock.

It is strictly forbidden to connect to your computer during this operation. You may connect to the computer after marking/basketing to upload the marking information to club management system.



When you select the **Race Marking**, you will get to the race list table to select the specific race you want to mark. After select the race, you will go to the marking page. The upper side is the **Race Information** of **Race Code**, **Liberation site** and **Liberation Date** and Time.

In the lower side there is the **Race Marking** window which will guide you throughout the race marking process. The process will be as follows:

1. Press RED **Start** button to start the marking process. The middle message will prompt "Waiting..."
2. You can start basketing/marketing your birds for the race continuously.
3. When you finish the basketing/marketing process, press **Stop** to finish this fancier's basketing/Marketing process.
4. The **Print** button then will activate to green color. A reminder window also popup to ask you to print the basketing/Marketing report. **You MUST print after finished the basketing/Marketing process.**
5. If you want to **remark** the birds after marking **STOP**. You can press cancel on the printing prompt. **Once you print the marking report the remark is forbidden.**
6. In case you did not connect to a printer, the display will show you "Print Failed". Then you press OK and the process will proceed.
7. After printing the Basketing/Marketing report, the race has been **Activated** and a **Pigeon** button will be activated to green color where you can check your birds that have been marked. A search window can help you to find the bird if you have too many birds in this marking.

 TOPIGEON - OFFICIAL RACE ENTRY

Club: AVANCE Lib Date: 07/05/2015 Lib Site: TAINAN
 Flyer's Name: Austin Loft Number: AVANCE-003
 Flyer's Street: Songliang Road Town/City: Tainan
 Post code: 105 Telephone No.: 0225163676

Set Time: 06/05/2015 04:11:23
 -Flyer's' Clock: 06/05/2015 04:11:22

Printed on: 06/05/2015 04:11:47 Clock Details: 25985C18
 Marker Id: 24c6f85b Key Code: 14b64e70

Race Code: 99990507 Lib Site: TAINAN

No.	Bird	Le-Ring	Sex	Color	Marked	
					Day	Time
1	NL15660003	1234567A1C	1	BUCB	09/01	01:41:28
2	NL15660004	17C8AFC791C	1	CHD	09/01	01:41:31
3	NL15660005	179PC82281C	1	BOPD	09/01	01:41:33

Marked: 3

Total hens: 0
 Total cocks: 3
 Yearlings: 3

All Birds entered come from a loft that has been fully vaccinated against
 paratyphoid and are registered in my name.

Signed: Flyer Club Clock Coaked

Sample of marking report

Unmark Birds

During the club operation, there might be some incident which happened after the birds have been swiped in club antenna in the basketing/marketing process. Such as the club staff found a disqualified bird or unhealthy bird, the club has to unmark such birds. You can simply


click on the  button on the **Racing Marking** and marked pigeon list will show, there is also a search window if you have more pigeons. Select the pigeon that you wish to unmark and press **Unmark** button.



When you press the **Unmark**, it will show a confirmation window to double confirm the un-marking process. If you press OK, it will unmarked the bird in this process.

Race Manager

The race manager can handle all the race operation in the club. Firstly you will go to a Race List where you can find all the active races. You can also Add Race manually in here.



Add Race


Note: This function is for manual operation only, if you are NOT using iPigeon Club Manager System. This function is used when all your club members are not using iPigeon club manager system (connect to PC) or when you join the club with FCI clocks and you have to manually type in the race information.

Press Add button then you will go to Add race screen. You can simply type in the race information in this window, including Club Code, Liberation Site and Liberation Date and Time. If you want detail online information or result calculation, please using the iPigeon club manager software to create the race information.

Close/Delete Race

After your birds return to the loft, you can bring the iPigeon to the club anytime you want, even if the birds have not all returned. When the iPigeon is connect to the club antenna with authorization key, the race information will show all the options for the club.

Close Race (Race Finalization)



You can also close the race directly by press the **Close** button. After you select the close a confirmation window will pop up and ask you to confirm if this is right race. In the arrival mode, you will see 2 buttons active in the race information, **Print**, and **Delete**.

Print: This is to print the race result and can print as many copies as you want. **However, you have at least to print once before you can delete this race.** Please also note that if you are using club manager software and upload the race result this will also give you an error message if you have not printed. The working flow as the diagram below,

Power up - select screen Club Manager



hold Fob over Well



on screen select Race Manager



On Race List
Select race to Close



Select Close




Select OK



Select Print



Select OK



Sample race printing report



Arrival Mode (Race in Progress)

After you click the **Arrive** button, a confirmation window will pop up and ask you to confirm if this is right race. In the arrival mode, you will see 2 buttons active in the race information, **Print**, and **Delete**.


Print: This is to print the race result and can print as many copy as you want. **However, you have at least to print once before you can delete this race.** Please also note that if you are using club manager software and upload the race result this will also give you an error message if you have not printed.



Delete Race

After you confirm the arrival result and close the race, then you can delete the race. The screen will show a warning message to confirm this deletion process which releases all birds from the race. This returns the clock back to the training mode and ready for the next race.

System Test



LCD test: The iPigeon screen is LCD and LCD will set the color calibration.

Ring test: In chip rings test will display the chip ring's e-ring number. You can use the iPigeon embedded RFID reader to do this test.

SMS test: Where you can type your mobile number to test the SMS feature. If your GSM power bar is showing the signal the SMS function should work.

Logs: This is the same as the System Info's System Log with more detail iPigeon technical commands. This feature provides you more transparent information of how this clock process. For example, when your pigeon is back to your loft and you will see the detail log has displayed this pigeon's ring number, back order, if GPS signal, SMS, internet, online

TOPIGEON

function and race information, including if secret code is read properly. This can provide your tracking and analysis tool if you have dispute with the club. This is also the how **TOPigeon Loft Monitor System** communication works.

The screenshot displays the TOPigeon mobile application interface. The top status bar shows GSM, GPS, RF, and the date/time 25/11/2014 14:28:00. The main screen is split into two panels. The left panel, titled "Enter Phone Number:", features a white input field and a blue "Send" button. Below this is a numeric keypad with buttons for digits 1-9, 0, and a red "x" for clearing. The right panel, titled "System Logs", contains a table with columns "No.", "Time", and "Type". The table lists log entries from No. 73 to 82. Entry 82 is highlighted in blue and shows the type "Unassignment". Below the table, a JSON object is displayed: {"assocNum": "BP-214-DNA-10001", "eringNum": ""}. At the bottom, a blue navigation bar includes a home icon, a back arrow, a forward arrow, and another back arrow.

No.	Time	Type
73	12/10/2015 10:46:43	Power on
74	12/10/2015 10:56:19	Power on
75	12/10/2015 10:59:12	Power on
76	12/10/2015 11:01:11	Power on
77	12/10/2015 11:06:36	Power on
78	12/10/2015 11:23:32	Power on
79	12/10/2015 11:59:44	Power on
80	12/10/2015 12:00:29	Power on
81	12/10/2015 12:13:15	Power on
82	12/10/2015 12:25:14	Unassignment

```
{"assocNum": "BP-214-DNA-10001", "eringNum": ""}
```



Club Antenna Operation

The club antenna is the center of club system operation, and it is very straight forward to use by reading the LED light on top of the panel. Club antenna based on powerful logical controller that provides all-in-one features and also intelligent workflow process in the club operation. The I/O ports provide club antenna standalone operation capability without any additional router. There are 2 mini-DIN, GPS, standard parallel port printer, and USB Virtual COM port (VCP) to connect all devices necessary for club operations.




Mini DIN



This is Mini Din which provides power and signal between Club Antenna and Clock. If the cable is not fully insert into the connector it will cause power unstable.

Please Note: There is an upside and downside on the plug and there is an arrow which is upside. For Club antenna the upside is facing UP and to the Clock the upside is facing DOWN.

Please also note, you have to FULLY insert into the plug, so you will see NO metal part come out.



Trouble Shooting:

There is ONLY ONE possibility if the cable cause problem. You can ask to replace this cable.

TOPIGEON

Please check the 4 pins of the plug and see if all the pins in the same position.

CAUSE: If the one or two PINs shorter may cause connection problem.



When you connect to iPigeon clock with the MiniDIN cable, it will also provide the power to iPigeon clock. The printer port is standard parallel port which support LPT IEEE1284 standard printer and the default printing size is A4. The external GPS module is an optional device which you can purchase from your local agent or TOPigeon.



There are 4 LED on top of the club antenna with different colors and the meaning of these LED light on or blink are as follows,

LED Light	ON	Flickering
 Power	Power on and system normal	Operation error or system error
 Transponder	Transponder read	Waiting to read a transponder (chip ring)
 Authentication Key	Club master authenticated	Need to present the application key
 Master Time	The club antenna RTC has synchronized by radio-clock or GPS signal	No radio-clock or GPS signal (NO master time)



If you are using the GPS module, make sure you plug to the right port, because it is similar to the computer port. The GPS module antenna must out access to the outdoor.

Declaration of Conformity

iPigeon Timer

AVANCETECH

Declaration of Conformity

The undersigned representing:

Manufacture	Contact
Avance Technology Co., LTD No.25, Lane 97, Songjiang Rd. 104, Taipei, Taiwan	Tel +886 2 2516 3676 Fax +886 2 2516 3682 Web: www.topigeon.com

herewith declares, that the product(s)

Devices Name
iPigeon


Is in conformity with the following EC directives(s), including all applicable amendments, and that the standards and/or technical specifications reference below have been applied:

Directive 2004/18/EC LVD 2006/95/EC Standards	Short Descriptions	
EMC	EN 550022: 2010 Class B EN 550022: 2010 Class B	Conducted disturbance of mains terminals Radiated Disturbance
	EN 61000-3-2: 2014 EN 61000-3-3: 2013	Harmonic current emissions Voltage Fluctuation and flicker
	EN 61000-4-2: 2009	Electronic Discharge (ESD)
	EN 61000-4-3: 2006+A2:2008+A2:2010	Radio-Frequency, Continuous radiated disturbance
IMMUNITY	EN 61000-4-4: 2012	FET/B immunity
	EN 61000-4-5: 2006	Surge Immunity
	EN 61000-4-6: 2009	Conducted RF immunity
	EN61000-4-11: 2004	Voltage dips/ interruptions
	EN 60950-1: 2006+A11: 2009+A1: 2010+A12: 2011+A2: 2013	Information technology equipment –Safety –Part 1: General requirements

This declaration is based upon the following technical documentation. The documents are held by the manufacture.

Report No.	Report Title
TB-EMC143173	EMC test report; Avancetech Co., LTD
TB-LVD143174	Test Report: Avancetech Co., LTD
TB-15019885	CE: Certificate of conformity

The product(s), listed above, are marked as following:



Taipei, 20.10-2015
Place and date of issue

Signature - Mr. Kuang C. Cheng
Chairman of Avancetech Co., LTD

4 Channel Landing Board

Declaration of Conformity

The undersigned representing:

herewith declares, that the product(s)

Manufacture	Contact
Avance Technology Co., LTD No.25, Lane 97, Songjiang Rd. 104, Taipei, Taiwan	Tel +886 2 2516 3676 Fax +886 2 2516 3682 Web: www.topigeon.com

Devices Name
4 Channel Landing Board

Is in conformity with the following EC directives(s), including all applicable amendments, and that the standards and/or technical specifications reference below have been applied:

Directive 2004/18/EC Standards	Short Descriptions
EMC EN 550022: 2010 Class B	Radiated Disturbance
EN 61000-4-2: 2009	Electronic Discharge (ESD)
IMMUNITY EN 61000-4-3: 2006+A2:2008+A2:2010	Radio-Frequency, Continuous radiated disturbance
EN61000-4-11: 2004	Voltage dips/ interruptions

This declaration is based upon the following technical documentation. The documents are held by the manufacture.


Report No.	Report Title
TB-EMC143177	EMC test report; Avancetech Co., LTD
TB-15019889	CE: Certificate of conformity

The product(s), listed above, are marked as following:



Taipei, 20.10-2015

Place and date of issue



Signature - Mr. Kuang C. Cheng

Chairman of Avancetech Co., LTD

1 Channel Landing Board

Declaration of Conformity

The undersigned representing:

Manufacture	Contact
Avance Technology Co., LTD No.25, Lane 97, Songjiang Rd. 104, Taipei, Taiwan	Tel +886 2 2516 3676 Fax +886 2 2516 3682 Web: www.topigeon.com

herewith declares, that the product(s)

Devices Name
Single Channel Landing Board


Is in conformity with the following EC directives(s), including all applicable amendments, and that the standards and/or technical specifications reference below have been applied:

Directive	2004/18/EC Standards	Short Descriptions
EMC	EN 550022: 2010 Class B	Radiated Disturbance
	EN 61000-4-2: 2009	Electronic Discharge (ESD)
IMMUNITY	EN 61000-4-3: 2006+A2:2008+A2:2010	Radio-Frequency, Continuous radiated disturbance
	EN61000-4-11: 2004	Voltage dips/ interruptions

This declaration is based upon the following technical documentation. The documents are held by the manufacture.

Report No.	Report Title
TB-EMC143175	EMC test report; Avancetech Co., LTD
TB-15019887	CE: Certificate of conformity

The product(s), listed above, are marked as following:



Taipei, 20.10-2015

Place and date of issue



Signature - Mr. Kuang C. Cheng

Chairman of Avancetech Co., LTD

Club Antenna

Declaration of Conformity

The undersigned representing:

herewith declares, that the product(s)

Manufacture	Contact
Avance Technology Co., LTD No.25, Lane 97, Songjiang Rd. 104, Taipei, Taiwan	Tel +886 2 2516 3676 Fax +886 2 2516 3682 Web: www.topigeon.com

Devices Name
Club Antenna


Is in conformity with the following EC directives(s), including all applicable amendments, and that the standards and/or technical specifications reference below have been applied:

Directive LVD 2006/95EC Standards	Short Descriptions
SAFTY EN 60950-1: 2006+A11: 2009+A1: 2010+A12: 2011+A2: 2013	Information technology equipment –Safety –Part 1: General requirements

This declaration is based upon the following technical documentation. The documents are held by the manufacture.

Report No.	Report Title
TB-LVD143857	Test Report: Avancetech Co., LTD
TB 150410269	CE: Certificate of conformity

The product(s), listed above, are marked as following:



Taipei, 20.10-2015

Place and date of issue



Signature - Mr. Kuang C. Cheng

Chairman of Avancetech Co., LTD



iPigeon Technical Data

- CPU: TI's DM 3730 ARM Cortex A8 (Datasheet attached)
- RAM: 256MB
- ROM :512MB
- Pigeon Data: Over 10,000 pigeons
- Main processor speed: 1GHZ
- 2" inches speaker for audio out
- 800* 480, 32bit, 7" inches color touch LED display.
- Dimensions: 248mm*135mm*3.5mm
- Interface: RS-232 / RS-485 serial port, CAN bus system 、 USB
- SD Memory Card Socket for firmware update
- 3G module: UMTS/HSPA/HSPA+/GSM/GPRS
- Power supply: Input: AC 110~240V/1.2A; Output: DC 12V/2A

